

## Congratulations!

You've just purchased a fine digital watch designed to provide years of accurate service.

Your LED watch has five functions — hours, minutes, seconds, month and date.



# TEXAS INSTRUMENTS INCORPORATED


## **ANYTIME** MICROELECTRONIC DIGITAL WATCH

T.M.

### How to Use Your Digital Watch

To use your watch, press the command button once for hours and minutes. If you continue to hold the button in, seconds will appear.

Press the command button twice quickly to see the date. Your TI watch has a calendar which automatically adjusts for short and long months.



### Setting Your Watch

Set your watch by pressing the recessed set button with a ballpoint pen. After pressing the set button, press the command button until the hour and the A(AM) or P(PM) is correct. Repeat the setting procedure for minutes, month and date.

Synchronize your watch by setting it one minute ahead and pressing the command button when the time reference catches up. Always press the command button after setting your watch to prevent excessive drain on the batteries.

### Time Zone Change Feature

You can change the hour and skip the rest of the setting procedure by holding the set button in for at least one second after changing the time.

### Battery Replacement


When the display dims noticeably, it is time to replace the batteries. The following batteries, or equivalent, can be used:

#### Models 405, 501, 503, 525, 526

Mallory Duracell 10L124  
Eveready UC-386

#### Model 625

Mallory Duracell 10L125  
Eveready UC-392



- Some TI watches have battery clips and some do not. If your watch looks like the one above, carefully slide each battery out from under the battery clip, using a small screwdriver.

**WARNING:** Do not unfasten the metal battery clip, as this can seriously damage your watch.

- If your watch does not have a battery clip, remove back and turn watch over. Batteries will fall out.

**CAUTION:** Be careful not to loosen or remove the module. If the module separates from the case, return the watch to TI for repair.

- Place one battery against the contact with a + sign, with the positive (flat) side down. Slide the other battery against the contact marked with —, with the negative (tapered) side down.
- Snap case shut with thumbs and forefingers. If the case doesn't close fully, put watch face up on the corner of a desk or table and close it with steady palm pressure.
- Press command button. If display does not light up, check to be sure batteries are installed correctly.
- Reset your watch. When batteries are replaced, timekeeping stops.

### Care of Your TI Watch

By following these suggestions, you can expect your watch to provide long, dependable service:

- **Exterior Care:** Your watch band can be cleaned with a cloth and mild soap, but should never be submerged in water. Minor scratches on the lens can be removed by cleaning with any commercial plastic polish with a cloth or tissue.

**WARNING:** Avoid strong chemicals, such as cleaning solvents, aerosol sprays, etc. which will destroy the seals and finish.

- **Water and Shock:** Do not wear your watch in water, as it is not waterproof. The watch can be affected by strong or repeated mechanical shock. For best results, avoid harsh and abusive treatment.

- **Safe Watch Storage:** Extended exposure to very hot or cold temperatures will affect the accuracy of your watch and may require resetting. Extended off-the-wrist exposure to temperatures below 0°F. (—17°C.) or above 140°F. (60°C.) can cause permanent damage to your watch.

### Mailing Instructions

Enclose a written explanation of the problem with your watch. Be sure to include your name and return address.

Wrap your watch in tissue or similar soft packing material and enclose it in a strong, crushproof mailing carton. If you use the original display box for mailing, it cannot be returned to you.

To protect your watch from theft, do not write "watch" or "Texas Instruments" on the outside of the package. U.S. customers should send watches to the address shown below:

TPDSC  
P. O. Box 2500  
Lubbock, TX 79408

Canadian customers should use the following address:

TI Service Facility  
41 Shelley Road  
Richmond Hill, Ontario

### Customer Assistance

Questions about TI consumer products can be answered by calling one of the toll-free numbers listed below:

1-800-527-4980 (Outside Texas)  
1-800-492-4298 (Texas Only)

TI watch owners in California and Oregon can contact the following offices for information or assistance:

Texas Instruments  
Consumer Service  
10700 S.W. Beaverton Hwy.  
Plaza Park West, Suite 111  
Beaverton, OR 97005  
503-643-6758

Texas Instruments  
Consumer Service  
3186 Airway, Bldg. J.  
Costa Mesa, CA 92626  
714-540-7190